


How to Use Rocklock


Rocklock Stemming Plugs Help Increase Blasting Safety & Improve Fragmentation



1. Select a Rocklock that is 90% of the borehole diameter. Then partially fill the Rocklock $\frac{1}{2}$ - $\frac{1}{3}$ full with stemming.



2. Approximately 1-1/2 times borehole diameter is loaded with stemming.
i.e. for 4 inch diameter borehole, 6 inches of stemming are filled.



3. Rocklock is dropped down borehole.



4. Fill stemming to top of hole.



The Rocklock stemming plug comes in a variety of sizes to match borehole diameter.

With unmatched performance, Rocklock delivers a substantial return on investment and offers significant bottom-line savings for the site.

Order Size Millimeters	Conversion to Inches	Hole Size	Units Per Package
38	1.5	2 - 2 1/2	Varies
45	1.75	2 1/4 - 2 3/4	Varies
75	2.95	3 - 3 1/4	250
90	3.51	4 - 4 1/4	115
100	3.94	4 1/2 - 4 7/8	100
115	4.48	5 - 5 1/4	50
125	5	5 1/2 - 6 1/8	38
137	5.5	6 1/4 - 6 1/2	50
150	6	6 5/8 - 7 3/8	Varies
200	7.8	9 - 9 7/8	Varies
235	9.14	10 - 10 3/4	Varies

Always use the correct ROCKLOCK with the appropriate borehole size to achieve optimum results. Please order by millimeter size.